CD Soundmachine

Easy access keyboard

- Digital tuner with 40 station presets
- Autostore presets
- Dynamic bass boost
- Bass reflex speaker system
- CD-Rewritable compatible
- 20-track CD programmable
- Shuffle play
- 14-key remote control
- CD synchro-start recording















CD Soundmachine

Standard product information

CD player

- Toploader with manual door
- · 20-track CD programmable
- · Shuffle play
- CD synchro-start recording
- · CD-Rewritable compatible
- Repeat one/ all/ program
- · CD next/ previous track search

Tuner

- · Digital tuning system
- · 40 station presets
- Autostore presets for quick programming
- · Direct preset input via easy access keyboard
- · Telescopic antenna for FM reception
- Internal antenna for AM reception
- Wavebands FM stereo

Tapedeck

- · Automatic recording level
- · Full auto stop

Sound system

- Output power 2 x 1 W RMS
- Dynamic bass boost
- · 2 x 4" speakers
- · Metal speaker grills
- · Digital up/ down volume control

Display

· 4-digit multi-functional LCD

Remote control

• 14 key Volume up/ down

CD play controls Tuner presets selection Tuner station search

Connections

· Headphone/ line out stereo, 3.5 mm

Power supply

AC/DC operation

Batteries
Remote batteries
6 x 1.5V, R14
2 x 1.5V, AAA

General

Product dimensions 15.9" W x 6.4" H x

9.1" D

Product weight TBC

Package dimension 18.7" W x 8.3" H x

10.2" D

Weight incl packing TBC

Easy access keyboard

Well-known 10 button interface for easiest possible tuner preset and CD track access.

Digital tuner with 40 station presets

Provides fast, accurate tuning to your favorite stations. You can store up to 40 FM and AM stations in memory for fast, easy access.

Autostore presets

Automatic programming of strongest available radio stations.

Dynamic bass boost

An electronic circuit that enhances bass frequencies up to 3 times to compensate for the insensitivity of the human ear for bass frequencies at lower volume levels.

Bass reflex speaker system

Acoustic system that enhances the upper bass tones to provide a warmer, punchier bass sound.

CD-rewritable compatible

CD player capable of playing all music CDs, including CD-Recordable and CD-Rewritable discs.

20-track CD programmable

Stores up to 20 of your favorite CD tracks for playing back in your order of preference.

Shuffle play

Plays all selections on a disc in random order, giving you a new sequence of tracks every time.

14-key remote control

Fully featured remote control for convenient operation of CD, volume and tuner controls.

CD synchro-start recording

One button touch will synchronize the start of a recording on audio cassette and the start of a CD or CD program.

4" Full-range speakers

For excellent sound reproduction across the entire audio spectrum.

Full auto-stop

Automatically shuts off the cassette deck at the end of playback to avoid stretching the tape.

Repeat one/ all/ program

Repeats the current track, the total CD, or your pre-selected program.

Stereo headphone socket

Supports stereo headphones for private listening pleasure. Automatically switches off speakers when used.

4-digit multi-functional LCD display

Displays CD player information (track, time, play mode), tuner information (preset station, frequency) and DBB on/off.

Digital up/ down volume control

Accurate electronic volume control with level indication.

UPC: 0 37849 91905 7

Printed 2001-11-16 Specifications subject to modification without notice © 2001 Koninklijke Philips Electronics N.V. All rights reserved

www.philips.com www.audio.philips.com



